

Considering Measurement Requirements for IBOC Radio

David Maxson

IEEE BTS 2004



Topics

- Guidelines for Spectral Occupancy
 - Host Compatibility
 - Spectrum Compatibility
- Power Measurements
 - •Uniform Methods
 - **■**IBOC Topologies

First Thought

- IBOC
 - Truly "Hybrid" of analog and digital
- Measurement issues
 - A & D Signals measured differently
 - Signals close in frequency
 - Digital potential for intermodulation

First Thought

- Compliance issues
 - FCC enforcement depends on repeatable, verifiable methods
 - Measurements should employ consistent technique(s)
 - Quality of service depends on industry self regulation
 - Measurement skills vary among radio stations



Power Reference

- Case Study of FM
- •FM analog carrier is the primary reference
- Digital carriers sometimes the reference
 - Suggested convention:
 - Using "dBc_{FM}" for analog FM reference
 - Using "dBc_{PM}" for IBOC Primary Main OFDM carrier power (stipulate bandwidth!)



Making the Measurement

- Spectrum analyzer
 - Convenient
 - **■**Familiar

but...

- ■Room for error
 - •There are many setting options—results vary.
 - Must be able to interpret the measurements.


FCC Power Reference

47 CFR 73.317

FM transmission system requirements


(b) Any emission appearing on a frequency removed from the carrier by between 120 kHz and 240 kHz inclusive must be attenuated at least 25 dB below the level of the <u>unmodulated carrier</u>. Compliance with this requirement will be deemed to show the occupied bandwidth to be 240 kHz or less.

Analog Power



Underlying Graphic From NRSC

Analog Power






Analog Power


- Often not convenient to interrupt modulation to set reference
- If so: Recommend 300kHz bandwidth
 - Common RBW on spectrum analyzers
 - •FM energy within 300 kHz B/W
 - Undesired energy normally outside this B/W
 - Experience shows reliable results

Analog Power



Measurements

KUVOFM only




Analog FM Spectral Mask

- 47 CFR 73.317
 - (b) 120 240 kHz
 - (c) >240 600 kHz
 - (d) >600 kHz

- $-25 \, \mathrm{dBc}_{\mathrm{FM}}$
- $-35 \, \mathrm{dBc}_{\mathrm{FM}}$
- $-80~dBc_{FM} \\ (or -43-10 log(W ERP))$

Broadcast Signal Lab FCC Analog FM Mask and iBiquity Hybrid Mask



iBiquity Hybrid Spectral Mask

• "For hybrid systems, measurements of the combined analog and digital signals shall be made by averaging the power spectral density of the signal in a 1 kHz bandwidth over a 30-second segment of time."

from HD Radio™ FM Transmission System Specifications, Rev. C, September 9, 2004

Digital Power




Figure 1. iBiquity FM IBOC system signal spectral power density

Digital Power

- IBOC "sidebands"
 - Primary Main
 - ± 129 to 198 kHz (69 kHz band, each side)
 - 191 Orthogonal Frequency Division Multiplexing (OFDM) carriers on each sideband
 - Primary Extended
 - ± 102 to 129 kHz
 - Up to 76 OFDM carriers on each sideband

Digital Power

- ◆ IBOC "sidebands"
 - OFDM Carriers , QPSK modulation

• Spacing per carrier: 363.4 Hz

• Power per carrier: -45.8 dBc_{FM}

• Power per kHz: -41.4 dBc_{FM}

• Power per PM sideband: -23 dBc_{FM}

• Total PM power: -20 dBc_{FM}

- Spectrum Analyzer
 - Variations among detection modes
 - •"Sample"
 - *Random sample in each "bin"
 - •Average of series of random samples (by averaging n sweeps)
 - •"Max-Min"
 - •Average Max and Min values in successive sweeps
 - Video filtering
 - Peak




- Analyzer Accuracy
 - ■OFDM is noise-like
 - Detecting noise-like waveforms
 - •Average of filtered noise can be expected to be 1.05 dB less than the RMS
 - •Log detection of filtered noise can be expected to under report level by additional 1.45 dB
 - •Effective Noise Bandwidth of RBW filters affects results, typically \pm tenths of a dB to 1.5 dB
 - •Sources: Agilent, Tektronix application notes



Typical Analyzer

Analyzer Accuracy

■Detecting Noise-like waveforms A-D




After Agilent PN 4395/96-1




Analyzer – Digital IF

- Analyzer Accuracy
 - Detecting Noise-like waveforms




After Agilent PN 4395/96-1


- Channel Power
 - Analyzer utility
 - Computes power in a bandwidth
 - -24.11 dBc_{FM}
 per 69 kHz




- Channel Power
 - Analyzer utility
 - Computes power in a bandwidth
 - -23.86 dBc_{FM}
 per 69 kHz



- Positive Peaks
 - Peak Hold
- Sample
 - Averaged
 - -42.8 to -44.3 dBc_{FM}/kHz









- ◆IBOC Primary Main "subcarriers"
 - Linear amplification
 - Push transmitter into compression
 - For more efficiency
 - Reduces hardware cost per watt
 - With compression comes intermodulation
 - "Spectral regrowth"





OFDM Carriers in same group interact with each other

Interference Potential



What
Should
this Ratio
Be?






Figure 1. iBiquity FM IBOC system signal spectral power density








Measurements

Spectrum analyzers



Peak Hold


Peak Average

Max-Min Average



Measurements


Spectrum analyzers



Any
accumulation
mode shows
relation
between PM
and regrowth



iBiquity RF Mask




Frequency, F, Offset Relative to Carrier	Level, dB/kHz
200-215 kHz offset	[-61.4 - (frequency in kHz -200 kHz) · 0.867] dB
215-540 kHz offset	-74.4 dB
540-600 kHz offset	[-74.4 - (frequency in kHz -540 kHz) · 0.093] dB
>600 kHz offset	-80 dB

Table 3: iBiquity FM Hybrid Mode Noise and Spurious Emission Limits



iBiquity RF Mask




Frequency, F, Offset Relative to Carrier	Level, dB/kHz
200-215 kHz offset	[-61.4 - (frequency in kHz -200 kHz) · 0.867] dB
215-540 kHz offset	-74.4 dB
540-600 kHz offset	[-74.4 - (frequency in kHz -540 kHz) · 0.093] dB
>600 kHz offset	-80 dB

Table 3: iBiquity FM Hybrid Mode Noise and Spurious Emission Limits



iBiquity RF Mask



600 kHz

Frequency offset, KHz

Frequency, F, Offset Relative to Carrier	Level, dB/kHz
200-215 kHz offset	[-61.4 - (frequency in kHz -200 kHz) · 0.867] dB
215-540 kHz offset	-74.4 dB
540-600 kHz offset	[-74.4 - (frequency in kHz -540 kHz) · 0.093] dB
>600 kHz offset	-80 dB


Table 3: iBiquity FM Hybrid Mode Noise and Spurious Emission Limits

iBiquity Hybrid Spectral Mask

- iBiquity note under Table 4-1
- "The requirements for noise and spurious emission limits defined in this subsection reflect acceptable performance criteria. In certain circumstances, additional measures (filtering, active emissions suppression, etc.) may be needed to reduce the spectral emissions below the limits given in this subsection in order to reduce mutual interference between broadcast stations."




Why Regrowth Matters



Field Measurement with 4th Adjacent Signals

What's Wrong with this Picture?






Separate Amplification

- Separate Amplification
 - Digital signal generated and amplified separately
 - Analog and digital run through combiner
 - "High Level Combining"
 - Analog and digital combined at antenna, or
 - Analog and digital on separate antennas
 - Regrowth primarily limited to 328-kHz intervals


Separate Amplification



Common Amplification

- Common Amplification
 - Analog Signal Amplified with Digital
 - More Points of Regrowth
 - Digital energy and analog energy intermodulate in common amplifier

Common Amplification



Precorrection

- Precorrection is Expansion
 - Anticipates the compression of the Power Amp
- What's the Opposite of "Compand"?
 - Compress-Expand = Compand
 - Expand-Compress = Express???? Empress????


Precorrection

- Compression Example:
 - A digital exciter without precorrection,
 measured 6-7 dB peak to average power ratio
 - After going through the PA,
 peak to average 4-5 dB

Precorrection

Without precorrection


Courtesy Harris Corp.



Precorrection

With fixed precorrection

Courtesy
Harris Corp.





Adaptive Precorrection

- Case Study
 - •KUVO, Denver
 - ■Nautel V-10 Transmitter



Adaptive Precorrection





Common Line

Analog and Digital exist together in the same transmission line prior to transmission from a common antenna

Low level combined


• Common amplification

High Level Combined

• Lossy hybrid combining

• 10-dB combining

• Split level combining






Common Line

*Sample points using directional couplers in


transmission line

■Common Line



Common Line

- How to Measure
 - Establish analog reference
 - Note: Presence of IBOC causes only
 ~0.05 dB error
 - Measure digital in presence of analog




Separate Line

• Analog and Digital do <u>not</u> exist together in an accessible transmission line prior to being radiated from either a common or separate antenna

Dual input antennas

Separate antennas




Separate Line

*Sample points using directional couplers in transmission line

Calibrated directional couplers

Separate Lines




Separate Line

- *Sample points using directional couplers in transmission lines
 - Calibrated directional couplers required
 - Must relate analog power to digital
 - •Typical coupling level: -40 dB
 - •Typical directivity: <-35 dB

Line

Separate Lines

- Relating Analog to Digital
 - Establish analog reference level
 - Use loss budget to relate to digital le



Coupling Losses

Sample Loss Budget for TPO Calcs

Station Call Sign	
Frequency (MHz)	

ERP (W)

Antenna Model	
Antenna Gain (multiplier)	

Antenna input power (W)

Main Horizontal and Vertical Line
Line Length (feet)
Line loss per hundred feet (dB/100')
Line loss total (dB)

Analog to Digital Isolation base of feedlines (dB)
Analog to Digital Isolation at Antenna Input (dB)
Analog to Digital Coupling Loss (dB)

Power Into Base of Vertical Line Run (W)

WX	(XX
88	3.1
Analog	Digital

50000 500

4-bay ERI Model		
1082-4	CP-DA	
4.67	4.67	

10707	107
10101	101

3-1/8" Rigid Coax	1-5/8" Heliax HJ7-50A		
500	500		
-0.0872	-0.190		
-0.4360	-0.9507		

-22
-20.61
-0.0379

11941 134

Sample Loss Budget for TPO Calcs

al Line Run (W	ertical	Base of	Into	Power
----------------	---------	---------	------	-------

Coupled Power at Filter Output Ports (W)

Filter Insertion Loss (dB)

Power Input to Filter (W)

Circulator Insertion Loss (dB)

Digital Power Input to Circulator

TX to Circulator Line	
Line Length (feet)	
Line loss per hundred feet (dB/100')	
Line loss total (dB)	

TPO (W)
-------	----

11941	134
75	1
-0.370	-0.450
13003	149
0	-0.45
NA	165
NA	1/2" Foam
	LDF4-50A
0	50
0.000	-0.619
0.0000	-0.310
13003	178

Courtesy of ERI



In Field

- Off-air sampling is most challenging
 - Localized multipath and fading can spoil accuracy of measurement
 - Adjacent signals may obscure regrowth
 - May be only way to see full hybrid signal



Summary

- Common Amplification
 - More points of spectral regrowth possible vs.Separate Amplification
- Common Line
 - Measure analog vs. digital directly
 - Separate lines require calibration
 - Directional couplers
 - Loss budget

Summary

- Analyzer setting
 - Must have good intermodulation specs
 - ■100-dB on-screen range helpful
 - ■1kHz RBW desirable
 - •But in a pinch, 3 kHz works
 - •Mind extraneous signals
 - ■Read The Manual!
 - •Total power into analyzer must be safely below analyzer compression
 - •Minimum measured signal must be above instrument noise floor

Summary

- Analyzer setting
 - Channel Power computation feature
 - Most desirable
 - Sample detection mode and multi-sweep averaging
 - •Good (15 sweeps OK, 50 pretty)
 - ■Max-Min (a.k.a. Pos-Neg) trace averaging
 - •Less precise
 - Very narrow Video Bandwidth
 - •In the ballpark, but slow and less precise.



- •A measurement protocol should be
 - Simple
 - Sufficient
 - Repeatable
 - Standard

- *Simple
 - Reasonably affordable equipment
 - Straightforward procedure

- **Sufficient**
 - ■Identify the least that needs measuring to confirm compliance and compatibility for enforcement (pass/fail)
 - Masks should suffice
 - Identify more precise methods for evaluating qualitatively
 - •Apply special case rules for certain adjacent channel issues, e.g. D/U ratios of adjacent stations versus co-channel spectral regrowth energy 67



- Repeatable
 - Licensees and regulators should test in same manner
 - Accept 2.5 dB adjustment for analog IF instruments
 - ■Use ENBW corrections only if results are borderline



- Standard
 - •NRSC would be a good source for a consensus on interference criteria and measurement protocols.
 - •If NRSC were to establish standards, FCC could validate and adopt.



Acknowledgements

Eric Wandel, ERI

Richard Hinkle, Broadcast Electronics

Geoff Mendenhall, Harris

Tim Hardy, Nautel



Thank You

Presentation will be available for download in the digital radio section at:

www.broadcastsignallab.com